Congratulations on your purchase of an Aria Brio high-intensity LED music light

Operation

To attach Brio to any solid-desk music stand, depress the spring-loaded clips in the back and slide Brio on the top lip of the stand. Turn the light on by rolling the thumbwheel. Adjust the light intensity to the level you desire.

Brio can operate either on battery or wall power. When you turn Brio on, the yellow status LED (underneath) indicates how much charge is left in the battery. Four blinks mean your battery is full. One blink means your battery is almost empty. A constant fast blink means the battery is completely empty and Brio will shut off very soon.

Charging

We recommend fully charging Brio before the first use to recalibrate the battery level meter. The battery charges only when the thumbwheel switch is completely off.

To charge, plug in the included power adapter and turn the thumb-wheel completely off (until it clicks). During charge, the yellow status LED is on for four seconds and off one second to indicate that the battery is charging. When the charge is nearly complete, the status LED stays on less often. When the status LED stays completely off, your battery is fully charged.

A full charge can take up to 14 hours. Brio uses a gentle charge that ensures long life for your battery. There is no need to fully discharge the battery before a charge. Charging early helps the battery last longer.

Cleaning

Clean smudges on the surface with a damp cloth. Do not get the LEDs, power cord, thumbwheel, status indicator, or power supply wet.

Accessories

Aria offers a number of accessories for your music light including a soft carrying case, replacement batteries and power supplies. Visit arialights.com to learn more. NOTE: Do not use any other power supply with your light or damage may result.







Brio uses NiMH batteries which contain recyclable materials. Consider recycling options available in your local area when disposing of this product. Do not dispose of in fire.

